



---

## FITTING INSTRUCTIONS

---

### BMW R1200GS Adventure – Auxiliary Light Guards



#### Contents

- 2 x Light Guards
- 2 x M5 x40 cap-head stainless steel bolts
- 4 x M5 stainless steel flat plain washers
- 2 x M5 nylock nuts

#### Looking at bike from front- for LEFT hand light guard

1. Prepare bolt by adding 1x M5 plain washer
2. Carefully loosen auxiliary light from bracket removing all original fixings.
3. Place the bolt and flat washer through the left hand side lug of the light guard.
4. Place light into light guard and push bolt through left hand fixing lug of auxiliary light.
5. Offer light and light guard to fixing bracket on bike and push bolt though until located within right hand fixing lug of left hand light.
6. Add flat washer and secure using nylock nut.
7. Repeat process as mirror image of above instructions for RIGHT hand light guard.

